


# Cobra System



1	TUBE ASSEMBLY
2	TUBE
3	TULIP
4	FOOT
5	HEAD ASSEMBLY
6	TOP COVER
7	COVER BEARING
8	SHAFT MAIN BEARING
9	QUADRANT GEAR
10	BOWL
11	THRUST BEARING
12	PINION INNER BEARING
13	CIRCLIP
14	FRONT SOCKET ASSEMBLY
15-16	SOCKET + BEARING
17	THRUST WASHER
18	PINION
18a	PINION KEY
19	SHIMS
20	BRAKE ASSEMBLY
21	BRAKE DRUM
22	BRAKE KEY
23	SEAL
24	BRAKE COVER
25-26-27	BRAKE KNOB-PAD-SCREW
29	DOWN SHAFT
29a	FEATHER KEY
29b	WOODRUFF KEY
30	BOTTOM SOCKET
31	LOWER BEARING

Fig. 12

